



1. H.V. Porcelain bushing
2. H.V. neutral Plug-in bushing
3. Tap changer on Reactor
4. Earthing terminal
5. Oil drain valve
6. Lifting lugs
7. Oil level indicator
8. Diagram plate
9. Rated plate
10. Neutral to earthing connector
11. Oil filling tube

kVA	A	B	C	k		n		Mass(kg)	
				H.V.	L.V.	H.V.	L.V.	Oil	Total
—	970	960	1430	260	—	385	—	380	1550

SUBcomp 20.5 25-50