



- 1. H.V. DIN-Bushings
- 2. H.V. neutral Plug-in bushing
- 3. L.V. DIN-Bushings
- 4. Tap changer on Reactor
- 5. Earthing terminal
- 6. Oil drain valve
- 7. Lifting lugs
- 8. Filling tube
- 9. Diagram plate
- 10. Rated plate
- 11. Neutral to earthing terminal

kVA	A	B	C	e	k		n		Mass(kg)		CNT 200-20,5
					H.V.	L.V.	H.V.	L.V.	Oil	Total	
200	1060	1010	1380	536	260	120	385	176	470	1710	